


# Guide to Using the Classroom PA Systems



These 2 knobs on the **back of the speaker** need to be turned on:



Set both of the highlighted volume knobs to the 12 o'clock position.

## IMPORTANT POINTS:

**A battery charger with extra AA batteries is located on a shelf inside the AV cabinet. Please leave batteries in the charger to keep them charged.**

**Please turn both of the speaker volume knobs off when you are done.**

## TROUBLESHOOTING:

When the microphone and the speaker are communicating, you'll see a solid green light on the microphone. If you instead see a red light, follow these steps to pair the speaker and the mic:

1. Turn on the speaker (the lower volume knob) then press and hold the "Pairing" button until green light for "Mic 1" flashes on the speaker. Then release the "Pairing" button.
2. Turn on the Mic then press and hold Mute button (the rocker switch where you turn volume up and down on the mic) until Mic red light turns off. Then release button.
3. Press and hold Mute button again on the mic until green light flashes.
4. The Mic is paired when the green light is solid on both the Mic and Speaker.